



Technical Service Bulletin

Technical Service Bulletin: tsb100631

Released Date: 14-Sep-2007

New Cylinder Block

New Cylinder Block

Warranty Statement

The information in this document has no effect on present warranty coverage or repair practices, nor does it authorize TRP or Campaign actions.

Contents

This Technical Service Bulletin introduces a new ISX cylinder block. This new cylinder block features a redesigned block heater port as well as the use of a new block heater and a new block heater port plug. The new cylinder block is backwards compatible to older cylinder blocks by virtue of installing a new block heater or block heater port plug. If a new block is ordered and the original engine was equipped with a block heater, a new style block heater, Part Number 4965497, along with the mounting capscrew, Part Number 3093957, **must** be ordered. If the original engine was **not** equipped with a block heater, a block heater port plug, Part Number 4985436, along with the mounting capscrew, Part Number 3093957, **must** be ordered. The old style block heater, Part Number 3681362, will still be available for service use.

New Part Number	Description	Old Part Number
4965679	Cylinder Block	3683646
4955718	Cylinder Block Kit (PBS (Memphis) Assembled)	4955502
4955719	Cylinder Block Kit (JEP Assembled)	4955474
4965497	Block Heater	Not Applicable
4985436	Block Heater Port Plug	Not Applicable
3093957	Capscrew	Not Applicable

Jamestown Engine Plant began phasing the new cylinder block into production on July 24, 2007. The Engine Serial Number first is 79259454.

