



# Technical Service Bulletin

Technical Service Bulletin: tsb101934

Released Date: 02-Aug-2006

Flywheel Capscrew Socket Tool Part Number

## Flywheel Capscrew Socket Tool Part Number

### Warranty Statement

The information in this document has no effect on present warranty coverage or repair practices, nor does it authorize TRP or Campaign actions.

### Contents

This Service Parts Topic identifies the need to add the flywheel mounting capscrew socket part number and correct a capscrew size in Procedure 016-005 of the service manual. The 21mm impact socket, Part Number 3162813, is **not** listed. The flywheel mounting capscrews and guide studs listed as M6 should be M16.

### Related Procedures

10-016-005-tr  
(/qs3/pubsys2/xml/en/procedures/10/10-016-005-tr.html)

Flywheel  
(/qs3/pubsys2/xml/en/procedures/10/10-016-005-tr.html)

Last Modified: 02-Aug-2006