



Technical Service Bulletin

Technical Service Bulletin: TSB120227

Released Date: 19-Jul-2012

Piston Cooling Gallery Plate Inspections on Heavy Duty Engines

Piston Cooling Gallery Plate Inspections on Heavy Duty Engines

Warranty Statement

The information in this document has no effect on present warranty coverage or repair practices, nor does it authorize TRP or Campaign actions.

Contents



02r00001

Before installing new or used pistons, inspect the condition of the piston oil cooling gallery plates. Pistons have been found with loose, broken, and missing plates. In all, cases, the piston is to be replaced and the new piston inspected.

Piston crown cooling and oil retention will be impacted by loose, broken, or missing cooling plates. In some cases progressive damage could occur such as scuffing, accelerated ring wear, accelerated liner polishing, etc.

Document History

Date	Details
2012-7-13	Module Created

Last Modified: 19-Jul-2012