



Technical Service Bulletin: TSB190159

Released Date: 05-May-2021

Air Compressor Pumping Noise Troubleshooting

Air Compressor Pumping Noise Troubleshooting

Warranty Statement

The information in this document authorizes specific changes to the repair practice for failures covered under product warranty coverages.

Contents

Product Affected

Engine:

- X15 CM2350 X114B
- X15 CM2350 X116B
- X15 CM2450 X124B
- X15 CM2450 X134B

Single Cylinder Air Compressor Options:

- CI1029
- CI1037
- CI1041

Dual Cylinder Air Compressor Option:

- CI1030

Original Equipment Manufacturer and Chassis:

- DTNA
 - Western Star
- Freightliner
 - Cascadia
- Kenworth
 - W900
 - T800
 - T880
 - T680
 - W990
 - C500
- Navistar

- LT
- Lonestar
- Peterbilt
 - 367
 - 389

Issue

Symptom:

- Drumming noise from the air compressor during operation.

Root Cause:

- Inability of the air plumbing system to dampen excessive sound waves is causing resonance in the system and leading to excessive noise.
- Air compressor drumming noise caused by system resonance will **not** lead to progressive engine damage or mechanical malfunction.

Verification

- Verify the air compressor pumping or drumming noise is present.
- The following audio link is a representation of air compressor pumping noise or drumming noise.

Note : http://videoprocedure.cumminsvirtualcollege.com/173-005-016_01_en.aspx
(http://videoprocedure.cumminsvirtualcollege.com/173-005-016_01_en.aspx)

Resolution

If air compressor pumping or drumming noise has been verified; call USA: 1-800-CUMMINS™ (1-800-286-6467) and reference this TSB number to be directed to the correct representative.

Document History

Date	Details
2019-9-10	Module Created
2019-9-20	Updated audio link.
2019-9-23	Quick Fix application:
2020-3-13	Updated Product Affected by adding X124B.
2021-5-5	Added more applicable products to this TSB.

