



Technical Service Bulletin

Technical Service Bulletin: tsb100950

Released Date: 17-May-2010

New Tachometer/Hourmeter

New Tachometer/Hourmeter

Warranty Statement

The information in this document has no effect on present warranty coverage or repair practices, nor does it authorize TRP or Campaign actions.

Contents

This Technical Service Bulletin introduces a new tachometer/hourmeter in kitted option EC 8258 for use on the K19 Series engines.

The new tachometer/hourmeter has a more robust design for improved component durability.

The installation procedure remains unchanged.

Both the mounting studs and the harness studs are recommended to be tightened to the standard of 0.68 to 0.90 N·m [6 to 8 in-lbs] with installation nuts.

The estimated time for introducing this change is 15-May-2010.

Note : The new tachometer/hourmeter is available for service. The previous version of the tachometer/hourmeter, Part Number 3049555, will still be available for service installation in control panels used in other applications.

Table 1, New and Old Part Numbers for K19 Series Engines

Description	New Part Number	Old Part Number
Tachometer/Hourmeter	4003713	3049555

Last Modified: 17-May-2010