



Technical Service Bulletin

Technical Service Bulletin: TSB180059

Released Date: 15-Jun-2018

New Water Inlet Connection

New Water Inlet Connection

Warranty Statement

The information in this document has no effect on present warranty coverage or repair practices, nor does it authorize TRP or Campaign actions.

Contents

Product Affected

- ISBE CM2150
- ISBE4 CM850
- ISB CM850
- ISB/ISD4.5 CM2150 SN
- ISB4.5 CM2150
- ISBE CM800

Description of Change

Minor casting changes made.

Service Instructions

- When replacing existing water inlet connection, Part Number 2830346, 2830974, or 4899530 with new Part Number 3979118 or 3979119, existing seal, Part Number 3906697, **must** be replaced with seal, Part Number 4983908.
- When replacing water inlet connection, Part Number 2830346, a threaded plug, Part Number 3089567, **must** be installed with a torque spec of 35 Nm [25 ft-lbs].

Service Parts Availability

Service parts are available. See Table 1 for part numbers.

Table 1, Service Parts

Part Description	Existing Part Number	Obsolete	Superseded	New Part Number	Required Seal Part Number	Required Plug Part Number
Water Inlet Connection	2830346	Yes	Yes	3979118	4983908	3089567

Table 1, Service Parts						
Part Description	Existing Part Number	Obsolete	Superseded	New Part Number	Required Seal Part Number	Required Plug Part Number
Water Inlet Connection	2830974	Yes	Yes	3979118	4983908	-
Water Inlet Connection	4899530	Yes	Yes	3979119	4983908	-

Document History

Date	Details
2018-5-17	Module Created

Last Modified: 15-Jun-2018
