



Technical Service Bulletin

Technical Service Bulletin: TSB110152

Released Date: 01-Jun-2011

K19 and QSK19 Flywheel Balance Holes Drilled in the Incorrect Location

K19 and QSK19 Flywheel Balance Holes Drilled in the Incorrect Location

Core Issue

The K19/QSK19 flywheel balance holes were drilled in the incorrect location on Part Number 3090758, and 3024105 flywheels. The flywheels are permitted for use and will have no effect on engine performance or durability. These flywheels have been installed on production engines and sold as service parts.

Confirmation

The balance holes in the flywheel should be on the outer most ring of the rear surface (1), but have been drilled on one of the inner rings (2). This is due to a supplier production error and does **not** affect the performance of the flywheel.




Resolution

Flywheels with balance holes in the incorrect locations are permitted for use and will have no effect on engine performance or durability. These flywheels are **not** defective and should **not** be returned.



Picture 1: Holes drilled in the incorrect location (Surface 2).



Picture 2: Holes drilled in the correct location (Surface 1).

Warranty Statement

The information in this document has no effect on present warranty coverage or repair practices, nor does it authorize TRP or Campaign actions.

Document History

Date	Details
2011-5-13	Module Created

Last Modified: 01-Jun-2011
